Security Policy Development Using GPO in Windows Server 2022 Lab

Task 1: Install Windows Server® 2022

- 1. Install VirtualBox.
- 2. Create a new virtual machine.
- 3. In the Actions pane, click Settings.
- 4. Under Hardware, click DVD Drive.
- 5. Click Image file, then click Browse.
- 6. Browse to the location of your Windows Server 2022 ISO file and select it.
- 7. Click Open, then OK.
- 8. In the Windows Setup Wizard, on the Windows Server 2022 page, verify the following settings, then click Next:
 - Language to install: English (United States)
 - Time and currency format: English (United States)
 - Keyboard or input method: US
- 9. Click Install now.
- 10. Select Windows Server 2022 Datacenter (Server with a GUI), then click Next.
- 11. Review and accept the license terms, then click Next.
- 12. Choose Custom: Install Windows only (advanced).
- 13. On the installation drive selection page, ensure there is enough space for the OS, then click Next.

Task 2: Change the Server Name

- 1. Sign in to the server as Administrator.
- 2. In Server Manager, click Local Server.
- 3. Click the computer name next to Computer name.
- 4. In System Properties, go to the Computer Name tab and click Change.
- 5. Enter the new name, e.g., CYSDC, in the Computer name text box, then click OK.
- 6. Confirm changes and restart the server.

Task 3: Change the Date and Time

- 1. Sign in to the server.
- 2. Click the time display in the taskbar.
- 3. In the pop-up, click Change date and time settings.
- 4. In the Date and Time dialog, select Change Time Zone, set your current time zone, then click OK.

5. Click Change Date and Time, confirm the settings, then click OK.

Task 4: Configure the Network

- 1. In Server Manager, click Local Server.
- 2. Next to Ethernet, click IPv4 Address Assigned by DHCP, IPv6 Enabled.
- 3. Right-click Ethernet and select Properties.
- 4. In Ethernet Properties, select Internet Protocol Version 4 (TCP/IPv4) and click Properties.
- 5. Select Use the following IP address and configure:

- IP address: 172.16.0.10- Subnet Mask: 255.255.0.0- Default Gateway: 172.16.0.1- Preferred DNS server: 172.16.0.10

6. Save settings and close dialogs.

Task 5: Install Active Directory

- 1. Open Server Manager and select Add roles and features.
- 2. Select Role-based or feature-based installation.
- 3. Choose the server from the server pool.
- 4. Select Active Directory Domain Services.
- 5. Click Add Features when prompted.
- 6. Confirm selections, check the Restart box, and install.
- 7. After installation, click Promote this server to a domain controller.
- 8. Select Add a new forest and specify a domain name (e.g., cys.local).
- 9. Set the Domain Services Restore Mode (DSRM) password and complete setup.
- 10. Reboot the server and verify Active Directory installation.

Task 6: Join a Windows 10 Client to the Domain

- 1. Prepare the Windows 10 Client:
- Ensure the Windows 10 client is connected to the same network as the Windows Server 2022 domain controller.
- Set the DNS server on the client to point to the IP address of the domain controller (e.g., 172.16.0.10).
- 2. Set the Client's DNS Server:
 - Open Control Panel > Network and Sharing Center.
 - Click on Ethernet (or the network connection being used), then select Properties.
 - Select Internet Protocol Version 4 (TCP/IPv4) and click Properties.
 - Choose Use the following DNS server addresses and set the Preferred DNS server to the

domain controller's IP address (e.g., 172.16.0.10).

- Click OK to save and close the properties.
- 3. Join the Domain:
- Open Settings on the Windows 10 client and go to System > About.
- Under Related settings, select System info.
- In the System window, select Change settings next to Computer name.
- In the System Properties dialog, go to the Computer Name tab and click Change.
- Select Domain and enter the domain name (e.g., cys.local).
- Click OK and, when prompted, enter the credentials of a domain account (e.g., the Administrator account from the domain controller).
- Once the computer is successfully joined to the domain, you will be prompted to restart. Select Restart Now.
- 4. Verify Domain Membership:
- After the restart, sign in using domain credentials (e.g., cys\username).
- Open System Properties and verify that the Domain field shows the domain name (e.g., cys.local).

Practice Questions for Task 6

- 1. What is the purpose of setting the DNS server on the client to point to the domain controller?
- 2. How would you troubleshoot a situation where the Windows 10 client cannot join the domain?
- 3. What are the benefits of joining a client to a domain in an enterprise environment?

Task 7: Configure Group Policy Objects (GPO)

- 1. Open Group Policy Management Console (GPMC):
- Sign in as Administrator.
- Go to Server Manager > Tools > Group Policy Management.
- 2. Create a New GPO:
- In GPMC, right-click the domain (e.g., cys.local) and select Create a GPO in this domain, and Link it here...
 - Name the GPO (e.g., "Security Settings") and click OK.
- 3. Edit the GPO:
 - Right-click the new GPO and select Edit.
 - Go to Computer Configuration > Policies > Windows Settings > Security Settings.
- 4. Configure Password Policies (Optional):
 - In Security Settings, go to Account Policies > Password Policy.
 - Configure settings like Minimum Password Length or Password Expiration as required.
- 5. Deploy the GPO:
- Close the editor.

- Right-click the domain and select Link an Existing GPO.
- Choose your GPO from the list, then click OK.
- 6. Verify GPO Application:
 - Run gpupdate /force on a client machine to apply settings immediately.
 - Use gpresult /r to confirm GPO settings are active.

Practice Questions for Task 7

- 1. Explain the purpose of Group Policy Objects in a networked environment.
- 2. How would you ensure GPO changes are applied promptly across client machines?
- 3. Describe a scenario where configuring a GPO would be advantageous in this setup.